RWNER'S MANUAL



SHOTL: CK

For SHOTLOCK™ ShotGun, CCW, 1911 and AR Solo-Vaults

SHOTL CK



OWNER'S MANUAL

For SHOTLOCK™ Shotgun, CCW, 1911 & AR Solo-Vaults

Thank you for purchasing a ShotLock™ Solo-Vault. Now, you can enjoy peace-of-mind knowing your personal defense firearm is always close, secure and ready. Now, when the first-responder is YOU, you're at-the-ready in seconds.

Note: Before using this product to transport any firearm or mounting in any type of vehicle, make sure you are conforming to all applicable local, state and federal laws.

IMMEDIATELY REGISTER YOUR SOLO-VAULT WITH THE ENCLOSED WARRANTY CARD.

PLEASE CAREFULLY REVIEW YOUR WARRANTY. ShotLock Solo-Vaults are covered by a 2-Year Limited Warranty, honored from the date of purchase by the original owner provided the accompanying postage paid registration card is returned within 30 days of purchase.




TABLE OF CONTENTS

Section I Shotgun Solo-Vault

Page 4 - Features

Page 4 - Parts List

Page 5 - Assembly

Page 6 - Mounting

Section II <u>CCW Solo-Vault</u>

Page 7 - Mounting and Features

1911 Solo-Vault

Page 8 - Mounting and Features

AR Solo-Vault

Page 9 - Mounting and Features

Section III All Solo-Vaults

Page 10 - Operation

Page 11 - Changing Combination Code

Page 12 - Troubleshooting

Page 13 - Warranty

Page 14 - Notes

Back Cover - Customer Service



Owner's Manual, Warranty Card and Foam Bed Liner Template (not shown)

SHOTGUN SOLO-VAULT FEATURES:

- Secures all pump, semi-auto and O/U shotguns*
- 14 gauge steel construction
- Double locking hooks
- 1000+ combination programmable push-button lock
- Reversible left or right opening door
 - *Ghost rings, scopes or sidesaddle shell carriers will not work with this product.

- Fully adjustable Trigger Blocks
- Pump Action Hanger
- Foam Bed Liners
- Multiple mounting holes
- MADE IN THE USA




SHOTGUN SOLO-VAULT ASSEMBLY

Semi-auto and O/U Shotguns

- 1. Lay Solo-Vault down either left or right opening, as preferred.
- Lay shotgun down inside Solo-Vault with bolt handle pointing up and position Trigger Blocks snugly around trigger assembly.
- 3. When the action is closed, bolt handle should be above the Solo-Vault, but as close as possible to the top of the door.
- 4. When the action is open, the handle will protrude through the hole in the door.
- 5. For left-handed shotguns Trigger Blocks may be mounted on left.
- 6. Trace positions of the Trigger Blocks onto the Foam Bed Liner Template and use template to cut Foam Bed Liners to fit around Trigger Blocks.
- Using M5x14mm screws attach Trigger Blocks to confine trigger assembly inside Solo-Vault.
- 8. Insert Foam Bed Liners.
- Adhere ShotLock logo to front of Solo-Vault.

Pump Shotguns

- 1. Lay vault down either left or right opening, as preferred.
- 2. For left-handed shotguns, Pump Action Hanger may be mounted top left.
- 3. Trace the position of the Pump Action Hanger onto the Foam Bed Liner Template, then use the template to cut Foam Bed Liners to fit around Hanger.
- 4. Using M5x14mm screws attach Pump Action Hanger to inside of Solo-Vault.
- 5. Insert Foam Bed liners.
- With action open, place ejection port over Pump Action Hanger.
- 7. Adhere ShotLock logo to front of Solo-Vault.



CCW SOLO-VAULT FEATURES

- Secures all compact and sub-compact semi-automatic pistols up to .380 and 9mm
- 14 gauge steel construction
- Double locking hooks
- 1000+ combination programmable push-button lock
- Reversible left or right opening

Size Inside: 7"H x 5"W x 2"D


- · Felt lined
- Cable attachment ports
- Multiple mounting holes
- MADE IN THE USA

MOUNTING YOUR CCW SOLO-VAULT

- Securely attach Solo-Vault in convenient location using 4 mounting screws (not provided).
- 2. Adhere ShotLock logo to front of Solo-Vault.
- 3. You may also secure your Solo-Vault by threading a heavy locking cable through the ports provided.



5/16" Cable Attachment ports




1911 SOLO-VAULT FEATURES

- Secures all full framed handguns up to sized 1911 framed semi-autos and revolvers.
- 14 gauge steel construction
- · Double locking hooks
- 1000+ combination programmable push-button lock
- Reversible left or right opening
- Carpet lined for extra protection.
- Cable attachment ports
- · Multiple mounting holes
- MADE IN THE USA

-8-

MOUNTING YOUR 1911 SOLO-VAULT

- Securely attach Solo-Vault in convenient location using 4 mounting screws (not provided).
- 2. Adhere ShotLock logo to front of Solo-Vault.
- 3. You may also secure your Solo-Vault by threading a heavy locking cable through the ports provided.



5/16" Cable Attachment ports

Size Inside: 9"H x 7"W x 2"D

Weight: 7 lbs



AR SOLO-VAULT FEATURES

- Accommodates one AR platform rifle
- · Accommodates top rail optics
- Accommodates up to 30 round magazine
- · Adjustable pistol grip hanger
- 1000+ combination program mable push-button lock
- 14 gauge steel construction
- 2 year limited warranty
- · Foam bed liner
- Can be mounted vertically or horizontally
- Reversible left or right opening door
- Multiple mounting holes
- MADE IN USA

MOUNTING YOUR AR SOLO-VAULT

- Determine desired mounting location.
- · Locate stud in wall.
- Secure AR Solo-Vault to stud using 3 mounting screws (not provided)



OPERATION

Unlocking

- 1. Turn knob left (counterclockwise) to CLEAR position and release. The knob will spring back to LOCK position and activate the buttons.
- 2. Enter current combination. (The factory set combination is 1-3-5)
- 3. Turn knob right (clockwise) to the UNLOCK position and open door.
- 4. Leave knob in UNLOCK position so that the ShotLock is in open position to receive the door.









Locking

- 1. Make sure knob is in the UNLOCK state so that the Solo-Vault is in the open position to receive the door.
- 2. Close door.
- 3. Turn knob left (counter-clockwise) to LOCK position.

FACTORY CODE COMBINATION						
 1		3	-	5		

CHANGING COMBINATION CODE

You can change your combination using one, or all 5 buttons, in any order. Two or more buttons may be pushed at a time, BUT each button can only be used once. Simple 2- and 3-button combinations are easy to remember and provide adequate security.

- 1. Open door and turn knob left (counterclockwise) to CLEAR position and release.
- 2. Remove two screws at either end of locking bar and remove lock cover.
- 3. Enter current combination.
- Depress reprogram button (marked red) inside the lock (opposite end from knob).
- 5. Turn knob left (counter-clockwise) to CLEAR position and release. This clears the <u>current</u> combination.
- 6. Press buttons firmly in desired sequence for <u>new</u> combination.
- 7. Turn knob right (clockwise) to UNLOCK position. This sets the <u>new</u> combination.
- 8. We recomend that you test your new combination with the door still open.
- 9. Replace cover.



Lock Cover Screw



Reprogram Button

RECORD NEW CO	MBINATION AND	KEEP IN A SAFE PLACE.
---------------	---------------	-----------------------

DO NOT TO LOSE YOUR COMBINATION CODE!

If you do, contact customer service at 800-967-8107. Regaining access will require a locksmith and/or returning your Solo-Vault to TruckVault for repair. If your Solo-Vault cannot be satisfactorily repaired, you will need to purchase a replacement.

TROUBLESHOOTING

PROBLEM 1

 Knob will not turn after combination has been entered.

POSSIBLE CAUSE

- a) Combination entered incorrectly or buttons not pressed firmly enough.
- b) Knob turned the wrong way.

SOLUTION

- a) Turn knob counter-clockwise to CLEAR buttons and reenter combination, making sure each button "clicks" when pushed.
- b) Reenter combination and turn knob clockwise to UNLOCK position.

PROBLEM 2

2. Buttons do not "click" when pressed.

POSSIBLE CAUSE

- a) Buttons were already pressed and not cleared.
- b) Buttons were not pressed firmly enough.

SOLUTION

- a) Turn knob counter-clockwise to CLEAR buttons.
- b) Turn knob counterclockwise to clear buttons, then press each button until it "clicks."

For all Customer Service questions call us toll free: 800-967-8107



LIABILITY DISCLAIMER AND FULL WARRANTY

TruckVault, Inc. guarantees to the original purchaser that the ShotLock™ Solo-Vault product is free from defects in material and workmanship for a period of 2 years (24 months) from the date of purchase.

In the event of any defects in material or workmanship, TruckVault's sole liability shall be to repair or replace the defective product or components, at its sole discretion. Allow six to eight weeks for repair or replacements.

The conditions and extent of the Warranty are as follows:

- If it becomes necessary to send the product to TruckVault, the product must be shipped in its original carton or equivalent, fully insured with all shipping charges prepaid. TruckVault is not responsible for any loss or damage incurred in shipping.
- Advance return authorization is required from our Customer Service Department (800-967-8107). If service on the product is required during the warranty period, obtain the authorization and send your product, together with a copy of your sales receipt with date of purchase (required), name, street, daytime telephone number and (if available) e-mail address to:

ShotLock c/o TruckVault PO. Box 734 / 211 Township Street Sedro-Woolley, WA 98284-0734

- This Warranty is void if (except for law enforcement personnel) the product is used for commercial purposes, or if service has been performed on the product by anyone other than TruckVault.
- This Warranty does not apply to any product that has been altered, misused, neglected or which has been used other than in accordance with the furnished instructions.
- Except to the extent prohibited by law, all implied warranties are disclaimed, including fitness for a particular purpose, merchantability and course of dealing or trade, and in no event shall they have greater duration than the warranty period set forth above.
- Under no circumstances shall TruckVault or its vendors be liable for any loss
 or any damage, injury or death, or direct, incidental, consequential or punitive
 damages arising out of or attributable to the malfunction, use or inability to use
 (including but not limited to because of a lost, misplaced, stolen or forgotten
 code) the product.
- Some states do not allow limitations on how long an implied warranty lasts or limitations or incidental or consequential damages, so THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

NOTES

			_	
			_	
			-	
			-	
			_	
			-	
			_	
_			_	
			_	
			_	



CUSTOMER SERVICE

For all Customer Service questions call us toll free: P: 800-967-8107 F: 360-855-2239

Or write:

ShotLock c/o TruckVault P.O. Box 734/211 Township Street Sedro-Woolley, WA 98284-0734

Or Email: info@truckvault.com

www.shotlock.com



SAFETY WARNING: Firearms are inherently dangerous and use of this product requires care and attention. Weapon storage, security and use are your personal responsibilities. Since TruckVault has no control over the firearm you use, the ammunition you carry and the manner in which you use the firearm or ammunition, it disclaims all related responsibility and liability. Your use of our product is at your own risk.

Using appropriate safety precautions with a loaded firearm is the sole responsibility of the person(s) using or handling the product. The user takes full responsibility for careless, inappropriate, improper, incorrect or negligent use of this product or related firearm. TruckVault and its vendors are not responsible for the misuse or mishandling of this product or of any weapon in connection with the product, nor for any personal injury, death or damage to you, or to anyone else, to any property or your weapon or anyone else.